



# Motion Computing LE1600 Battery Replacement

In this guide you will learn how to remove the battery from the device, as well as replace it.

Written By: David Troy



## INTRODUCTION

Before you start anything, you should always remove the battery. This guide will take you through this process.



## Step 1 — Battery



- Turn the device so the screen is facing down.

## Step 2



- Slide the battery lock switch next to the power slider to the unlocked position.

## Step 3



- Slide and hold the switch by the fan vent to the unlocked position. Firmly grasp the battery and pull away from tablet.
- ☑ When replacing the battery, place the end near the fan vent in first. Make sure to keep the other switch in the unlocked position while pushing the battery into place.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-19 09:19:53 AM.